



REMOTE BLOKE

How to Program a B&D Tri Trans Garage Door Remote

I recommend that you first read the instructions to ensure you have a clear understanding of the process.

PowerDrive & Roll A Pro and Motors prior to 2021

1. On your garage motor press the Code Set button and release, LED will illuminate to indicate Learn Mode.
2. On your new remote press the button you wish to activate your opener, the LED will begin to flash.
3. Press the button again, LED will illuminate then turn off.
4. The new remote is coded.

Smart Pro, Smart and Secure

1. On your garage motor remove the controls cover to access the buttons.
2. Press MODE until the remote indicator LED is lit.
3. Press and hold the DOWN arrow, remote indicator light will flash rapidly.
4. Press the button you wish to activate on your new remote.
5. Press the button again.
6. Press MODE button to exit Learn Mode, replace the control cover.
7. Your new remote is now coded.



0458 910 752



sales@remotebloke.com.au

